



外形安装尺寸 Mounting Dimension Sheets-overview

R147




电机需方配时或配特殊电机时需加联接法兰
When equipping the user's motor or the special one, the flange is required to be connected.




RF147


Φ450




R..S147



Φ550



R..147R87(R77)



	R..147R77组合	R..147R87组合
L	226	275

注：其余尺寸见相应的结构形式
Note: For other values please refer to the oppsited structure

Y2电机机座号 Motor size	160M	160L	180M	180L	200	225S	225M	250	280S	280M
功率/4P Power/(kW)	11	15	18.5	22	30	37	45	55	75	90
L3	567	602	583	616	654	674	696	775	845	845
G	330	330	380	380	420	470	470	510	580	580
L2	132	132	132	132	132	143	143	174	174	174

注：“R..”表示R、RF

Note：“R..”mean R、RF