



# 外形安装尺寸 Mounting Dimension Sheets-overview


## R27





电机需方配时或配特殊电机时需加联接法兰  
When equipping the user's motor or the special one, the flange is required to be connected.




## RF27



## R..S27



## R..27R17



注：其余尺寸见相应的结构形式  
Note: For other values please refer to the opposite structure

Y2电机机座号 Motor size	63	71		80		90S	90L	100	
功率/4P Power/(kW)	0.18	0.25	0.37	0.55	0.75	1.1	1.5	2.2	3.0
L3	235	245		278		304	328	340	
G	130	145		175		195	195	215	
L2	71	71		71		71	71	93	

注：“R..”表示R、RF      Note:“R..”mean R、RF